



DRAINAGE SUBMERSIBLE PUMP

OPERATION & Service Manual of the CorroTuff CT & CTS SERIES

www.pumpeng.com.au

Manual Contents

01.	Company Profile	2
02.	Introduction	6
	 Safety terminology and symbols Product warranty Safety User safety Environment safety 	6 7 8 9
03.	Product Description	10
	1.) Pump design 2.) Intended use 3.) The data plate 4.) Pump part names	10 10 12 12
04.	Prior to Use	13
	 Inspect the product Inspect the specification Product specification Method of starting 	13 13 13 13
05.	Installation	14
	 Preparation for installation Install the pump Make the electrical connections Grounding Connecting the cables 	15 16 19 19 20
06.	Operation	22
	1.) Before operation 2.) Trial operation 3.) Operation 4.) Motor protection system 5.) Water level during operation	22 23 25 26 27
07.	Maintenance and Inspection	28
	 Inspection Storage Maintenance Disassembly and reassembly procedure 	29 29 30 32
08.	Trouble Shooting	35

Introducing PumpEng

Company Profile

PumpEng is an Australian company founded in 2001 that specialises in submersible pumps for use in mining, construction and industrial dewatering. Founder Paul Meneghel has experience in submersible pumps and mining stretching back to the 1980s.

PumpEng uses innovative design to manufacture pumps that perform well in the toughest of circumstances. PumpEng has been successful in the Australian market with its innovative line of Raptor® pumps. Now PumpEng have launched a new pump - JetGuard®- that uses patented design innovations to better handle underground mining conditions including the presence of Shotcrete fibre and other tramp material.

Introducing JetGuard®

What Does a Broken Pump Really Cost a Mining Operation?

Many dewatering pumps were designed before Shotcrete was widely used in underground mining. Shotcrete fibres are now a major cause of underground pump failure and production delay. In a multi million dollar operation, even small delays can be expensive.

Benefits of JetGuard® for Mining Operations

- Performance: increase mine performance, productivity and profit by reducing breakdowns and delays.
- Safety: reduce workplace hazards by reducing the number of breakdown maintenance events.
- Cost: reduce equipment life cycle cost by increasing total pump life.

Why is JetGuard® Better?

PROTECTED - Less Fibre Gets In

A hydraulic curtain repels surface fibre, and the suction strainer intake is on the bottom of the pump, not the side. So less Shotcrete fibre gets inside. If any fibres do get in, a cutter plate chops up fibres into tiny pieces.

TOUGHENED - Less Damage Gets Done

Internal components in the wet end are tough metal, not elastomer. Fibre and tramp can more quickly destroy elastomer components, while toughened steel components power on. The mechanical seal is in a non pressurised zone, away from the high pressure intake area and removed from the fluid/Shotcrete path.

PRODUCTIVE - Less Downtime More Production

 ${\sf JetGuard}^{\textcircled{B}}$ has been designed for tough environments, to keep on pumping when traditional dewatering pumps might fail.



Capability Statement

Submersible Pump Range

PumpEng manufacture and sell tough submersible pumps suitable for underground mining and other heavy duty applications. We innovate to increase operational reliability and productivity.

JetGuard®	Heavy duty underground dewatering pump. Shotcrete handling capability, all metal wet end, electro submersible pump with high chrome impeller. 10Kw (20Kw and 37Kw planned)
Raptor® Underground dewatering submersible. Compatible with Xylem/Flygt Bil 5Kw to 20Kw Disclaimer: PumpEng Pty Ltd is not an authorized distributor of parts or s the products of Xylem. PumpEng Pty Ltd products are not associated with by or sponsored by Xylem. Any use of Xylem names, trademarks, model no, item no- for reference purpose only. Flygt is a registered trademark of Xylem.	
ScatPump®	Heavy duty submersible sludge/slurry pump with high chrome impeller & agitator. Flows available up to 83 l/s and heads up to 35 m. 1.5Kw to 22Kw
CorroTuff ®	A 415v range of pumps with smart technology. Stainless Steel with a HRC impeller. 1.5Kw to 22Kw
Vortex	A pump designed to handle solids without damaging the product. 4Kw to 18.5Kw
MetalVest	MetalVest [™] submersible pumps use a full metal build, so there is no urethane or rubber lined parts for a longer life available in 1000v & 415v. The cylindrical MetalVest [™] HHS Slimline is designed for those places where physical size is an issue. It fits inside caissons for offshore requirements. 4Kw to 18.5Kw The Heavy Duty MetalVest HH for those tough conditions 37kw.
Grinder	Small 240v grinder pump for dirty water applications. 0.75Kw to 1.1Kw

Parts, Hire & Service - A Full Service Provider

PumpEng stock an extensive range of spare parts. The entire range of PumpEng submersible pumps is available for hire Australia wide on short and long term contracts.

A range of service programs are available, and can be tailored to your requirements.

To ensure you never pay too much for our services, we offer a price guarantee on our product range. This effectively caps your maximum repair price. Simply send us your old pump if it goes over our limit and we will supply you with a PumpEng manufactured replacement.

Vision & History

Our vision is to be the specialist in tough submersible dewatering pumps based on:

- Innovative thinking: To offer solutions to customer needs.
- Product availability: Products available on time every time.
- Technically sound product & system advice: Supplying the correct product every time.
- After sales support: Providing support to our customers after the initial sale.

Our goals are:

- Develop & manufacture our own product range to give us product security and introduce these products into the market place with respect to our core values.
- Develop brand name & product recognition of our products to ensure future growth, security & profit.

PumpEng is an Australian company founded in 2001 that specialises in submersible pumps for use in mining, construction and industrial dewatering. Founder Paul Meneghel has experience in submersible pumps and mining stretching back to the 1980s. We are now a well established specialist submersible pump supplier to a wide range of customers across Australia, and are addressing global opportunities.

We have developed a team of experienced staff enabling us to satisfy our customers needs which vary from the design, manufacture and supply of our pumps to the expedient repair/ rebuild & full aftermarket support of our product range. The skills of our staff are further enhanced through the alignment of PumpEng with major foundries and engineering facilities located within Australia as well as abroad.

PumpEng's philosophy is to provide exceptional product and follow on with first-rate sales service and support. We aim to provide a Total Dewatering Solution.

Plant & Equipment

Our Perth, Kalgoorlie & Mount Isa branches comprise of stock holding as well as assembly, testing, fabrication and repair facilities. We have all the equipment needed to fully support our pump range including a custom built test facility which is able to test to AS 2417 Standards.

Our workshop is one of the few pump facilities in Western Australia incorporating a 1000v test bay and is equipped with a 200kva, 1000v transformer. Our manufacturing facilities in Western Australia and internationally have strict adherence to quality procedures throughout all stages of manufacture.

Warranty

PumpEng will repair faults in the products we manufacture within the following constraints:

- The fault has been caused by defects in materials or workmanship.
- The fault has occurred when the product is used in circumstances to which the product was intended to be operated in and in accordance with installation and operating recommendations.
- All repairs and regular maintenance is performed by an authorized PumpEng repair dealership.
- All components used in servicing and repairs must be genuine PumpEng components.
- The fault is not caused by inadequate maintenance.
- The fault occurs and is reported to PumpEng or an authorized PumpEng dealership within twelve (12) months of purchase.
- The product is returned to PumpEng or an authorized dealer at nil expense to the receiver.
- PumpEng accepts nil liability for consequential damage or losses.
- PumpEng reserves the right to alter information and specifications without notice.

Purpose of This Manual

Introduction

The purpose of this manual is to provide necessary information for:

- Installation
- Operation
- Maintenance

CAUTION:

Read this manual carefully before installing and using the product. Improper use of the product can cause personal injury and damage to properly, and may void the warranty. **NOTICE:**

Save this manual for future reference, and keep it readily available at the location of the unit.

Safety Terminology and Symbols

About Safety Messages

Is is extremely important that you read, understand, and follow the safety messages and regulations carefully before handling the product. They are published to help prevent these hazards:

- Personal accidents and health problems
- Damage to the product
- Product Malfunction

Hazard Levels

HAZARD LEVEL	INDICATION
DANGER:	 A hazardous situation which, if not avoided, will result in death or serious injury.
WARNING:	 A hazardous situation which, if not avoided, could result in death or serious injury.
	 A hazardous situation which, if not avoided, could result in minor or moderate injury.
NOTICE:	 A potential situation which, if not avoided, could result in undesirable conditions. A practice not related to personal injury.

Introduction

Hazard Categories

• Hazard categories can either fall under hazard levels of let specific symbols replace the ordinary hazard level symbols. Electrical hazards are indicated by the following specific symbol:

ELECTRICAL HAZARD:

These are examples of other categories that can occur. They fall under the ordinary hazard levels and may use complementing symbols:

- Crush hazard
- Cutting hazard
- Arc flash hazard

Product Warranty

Coverage

PumpEng undertakes to remedy the following faults in products sold by PumpEng under the following conditions:

- The faults are due to defects in design, materials or workmanship.
- The faults are reported to an PumpEng representative within the warranty period.
- The product is used only under the conditions described in this manual.
- The monitoring equipment incorporated in the product is correctly connected and in use.
- All service and repair work is done by personnel authorized by PumpEng.
- Genuine PumpEng parts are used.

Limitations

The warranty does not cover faults caused by the following:

- Deficient maintenance.
- Improper installation.
- Modifications or changes to the product and installation carried out without consulting PumpEng.
- Incorrectly executed repair work.
- Normal wear and tear.

PumpEng assumes no liability for the following:

- Bodily injuries.
- Material damages.
- Economic losses.

Warranty Claim

PumpEng products are high-quality products with expected reliable operation and long life. However, should the need arise for a warranty claim; please contact your PumpEng representative.

Spare Parts

PumpEng guarantees that spare parts will be available for 10 years after the manufacture of this product has been discontinued.

NOTICE:

When purchasing pump parts, please provide product code showed at the nameplate.

Safety

WARNING:

- The operator must be aware of safety precautions to prevent physical injury.
- Any pressure-containing device can explode, rupture, or discharge its contents if it is over-pressurized. Take all necessary measures to avoid over-pressurization.



- Operating, installing or maintaining the unit in any way that is not covered in this manual could cause death, serious personal injury, or damage to the equipment by PumpEng. If there is a question regarding the intended use of the equipment, please contact an PumpEng representative before proceeding.
- This manual clearly identifies accepted methods for disassembling units. This methods must be adhered to. Trapped liquid can rapidly expand and result in a violent explosion and injury. Never apply heat to impellers, propellers, or their retaining devices to aid in their removal.
- Do not change the service application without the approval of an authorized PumpEng representative.

CAUTION:

You must observe the instructions contained in this manual. Failure to do so could result in physical injury, damage, or delays.

User Safety

General safety rules

These safety rules apply:

- Always keep the work area clean.
- Pay attention to the risks presented by gas and vapors in the work area.
- Avoid all electrical dangers. Pay attention to the risks of electric shock or arc flash hazards.
- Always bear in mind the risk of drowning, electrical accidents, and burn injuries.

NOTICE:

Never operate a unit unless safety devices are installed. Also see specific information about safety devices in other chapters of this manual.

Introduction

Electrical connections

Electrical connections must be made by certified electricians in compliance with all international, national, state and local regulations. For more information about requirements, see sections dealing specifically with electrical connections.

Hazardous Liquids

The product is designed for use in liquids that can be hazardous to your health. Observe these rules when you work with the product:

- Make sure that all personnel who work with biological hazardous liquids are vaccinated against diseases to which they may be exposed.
- Observe strict personal cleanliness.

Wash the skin and eyes

Follow these procedures for chemicals or hazardous fluids that have come into contact with your eyes or your skin:

CONDITION	ACTION
Chemicals or hazardous fluids in eyes	 Hold your eyelids apart forcibly with your fingers. Rinse the eyes with eyewash or running water for at least 15 minutes. Seek medical attention.
Chemicals or hazardous fluids on skin	 Remove contaminated clothing. Wash the skin with soap and water for at least 1 minute. Seek medical attention, if necessary.

Environmental Safety

The work area

Always keep the station clean and/or discover emissions.

Waste and emissions regulations

Observe these safety regulations regarding waste and emissions:

- Dispose appropriately of all waste.
- Handle and dispose of the processed liquid in compliance with the applicable environmental regulations.
- Clean up all spills in accordance with safety and environmental procedures.
- Report all environmental emissions to the appropriate authorities.

Electrical installation

For electrical installation recycling requirements, consult your local electric utility.

Recycling Guidelines

Product Description

Always recycle according to the guidelines listed below:

- Follow local laws and regulations regarding recycling if the unit or parts are accepted by an authorized recycling company.
- If the first guidelines is not applicable, then return the unit or parts to the nearest PumpEng representative.

Pump Design

FLUID	TYPE/TEMPERATURE	Work drainage and sand carrying/0 to 40°C	
	IMPELLER	Open or Close	
PUMP	SHAFT SEAL	Double mechanical seal	
	BEARING	Sealed ball bearing	
	TYPE, POLES	Dry type submersible induction motor 2 poles, 4 poles	
	INSULATION	Class F	
MOTOR	MOTOR PROTECTOR (BUILT-IN)	Circle thermal protector	
		Miniature protector (Non-standard parts)	
	LUBRICANT	Turbine oil VG32	
DISCHARGE CONNECTION		House coupling, Hard pipe	

Intended Use

The product is intended for moving waste water, raw and clean water. Always follow the limits given in Application limits (page 9). If there is a question regarding the intended use of the equipment, please contact a PumpEng representative before proceeding.

WARNING:

Only Ex-approved pumps may be used in an explosive or flammable environment.

NOTICE:

Do not use the pump in highly corrosive liquids.

Pump Description The Data Plate & The Information of Pump Model



® SUBMERSIBLE CE	M 1.5 F Metal power (kW)
NO. (15)	diameter(inch)
MODEL (1) SAP. (16) -	Submersible drainage
○)DISCHARGE 10 mm HEAD MAX. 11 m(○	pump series
FREQUENCY (4) Hz CAPACITY MAX. (9) m ³ /min	
2 PHASE INDUCTION MOTOR OUTPUT (5) kW	M 1.5 F
3 V 7 A	│
6 r/min I CL ⑧ IP 68 \	Discharge hose inner
T.max. 12 (13 kg (14 m	diameter(inch)
	Submersible drainage pump series

NO.	LEGEND	NO.	LEGEND
1	Pump model	9	Max. capacity
2	Motor phase number	10	Discharge bore
3	Rated voltage	11	Max. total head
4	Frequency	12	Max. liquid temperature
5	Power	13	Weight
6	Speed	14	Mas. immersion depth
7	Rated current	15	Serial number
8	Thermal class	16	Product code

Pump Part Names

Product Description



NOTE:

This diagram shows the part layout of a typical CT/CTS model. The external appearance and the internal construction may vary slightly, depending on your particular model.

Pump Description

CTS technical data and function

NO.	CATEGORY	SET VALUE	ACTUATION TIME (s)	RECOVERY TIME (s)	RECOVERY MODE (s)
1	Phase loss	_	2	_	Manually recovery (Manually turn off the power correct the power turn on the power, pump works.
2	Impeller jam	Double rated current	0.1	_	Manually recovery (Manually turn off the power solve the problem turn on the power, pump works.
3	Phase sequence protection	With power line input errors, the pump won't work	_	_	Manually recovery (Manually turn off the power switch the input turn on the power, pump works.
4	Over-current protection	≥1.2 times rated current	30	300	Automatic recovery
5	Low-voltage protection	≤323V	5	300	Automatic recovery
6	Overvoltage protection	≥460V	5	300	Automatic recovery
7	Temperature protection	Winding ≥125±5°C	0.1		Automatic recovery (Winding≤80±10°C)
8	Water level control	Stated otherwise		_	_

NOTE:

CTS Metal head of electrode will be ON when touching the water, OFF when leaving water.

CTS Water-level Control Mode

- a. When the pump is power on, if floating switch (or water-level detector) is "ON", it means the pump starts to work.
- b. In the running of the pump, if floating switch (or water-level detector) is "OFF". it means the pumps will stop working after 60s continuous working, but if floating switch (or water-level detector) is "ON" again in 60s after "OFF", the pump will be non-stop.
- c. Stop time: After the pump stops for low water-level, it will not start within 60s even if floating switch (or water-level detector) is ON; unless plug in the power again after power off.
- d. Recovery mode: The pump stops for low water-level, it will start automatically after 60s when floating switch (or water-detector) is ON.

Inspect the Product

Prior to Use

- 1.) Inspect the package for damaged or missing items upon delivery.
- 2.) Unpack the package and verify that no damage has occurred during shipment and that bolts and nuts have not loosened.
- 3.) File a claim with the shipping company if anything is out of order.

NOTICE:

If the product has been picked up at a distributor, make a claim directly to the distributor.

Inspect the Specification

Check the nameplate of the pump unit to verify that it is the product that you have ordered. Pay particular attention to its voltage and frequency specifications.

NOTICE:

If you discover any damage or discrepancy, please contact with the PumpEng dealer from whom you purchased the product or the nearest PumpEng representative office.

Product Specification

CAUTION:

Do not use the product under conditions other than those specified. Doing so may lead to short, electrical shock, or fire, or might inhibit the product from attaining its full potential.

Method of Starting

Direct-on-line start.

DANGER:	 Disconnect and lock out electrical power before installing or servicing the unit. 	
	 Do not install the starter equipment in an explosive zone unless it is explosion-proof rated. Make sure that the unit cannot roll or fall over and injure people or damage property. 	
	 Electrical shock hazard. Check that the cable and cable entry have not been damaged during transport before installing the pump. 	
NOTICE:	Never force piping to make a connection with a pump.	

These requirements apply:

- Use the pump dimensional drawing in order to ensure proper installation.
- Provide a suitable barrier around the work area, for example, a guard rail.
- Check the explosion risk before you weld or use electric hand tools.
- Remove all debris from the inlet piping system before you install the pump.
- Always check the impeller rotation before lowering the pump into the pumped liquid.

CAUTION:

- The supply voltage variation:
 a. continuous running: max ±5% of the rated voltage.
 b. intermittent running: max ±10% of the rated voltage.
- To use the pump, the water temperature should be between 0°C and 40°C.
- The pump should be used only for pumping plain water. The pump should not be
- used to pump fluids such as oil, salt water, organic solvents. • The pump must never be used to pump explosive liquids and should not be operated
- The pump must never be used to pump explosive liquids and should not be operated in an area from whom explosive elements might be present.
- The pump must not be used in a partially disassembled state.
- Do not use the pump in an area where the water pressure exceeds the values given below, as it may damage the pump, or cause a short or electrical shock.

Maximum Immersion Depth

MODEL	Maximum immersion depth	
CT 0.25 ~ 0.75 kW	0.2MPa(2kgf/cm ²)-Discharge pressure during use	
CT/CTS 1.5 ~ 5.5 kW	0.5MPa(5kgf/cm ²)-Discharge pressure during use	
CT/CTS ≥ 7.5kW	0.6MPa(10kgf/cm ²)-Discharge pressure during use	

Preparation For Installation

Installation

Listed below are tools and instruments that are needed to install the submersible pump for general dewatering purpose.



Wrenches for fastening bolts and nuts

Wrenches for connecting the power supply (a screwdriver or a box wrench)

Pre-installation Check

Measure the resistance between each of the core wires and the ground wire (yellow/green) to verify the insulation resistance of the motor.

NOTE:

Insulation resistance reference value ≥30MΩ

Install the Pump

The pump is transportable and intended to operate either completely or partially submerged in the pumped liquid. The pump is equipped with a connection for hose or pipe.

- Run the cable so that it has no sharp bends, is not pinched, and cannot be sucked into the pump inlet.
- 2.) a. Soft pipe installation:

Push the hose all the way to the base of the hose coupling. Tighten the hose clamp to secure the hose in place.



b. Hard pipe installation:

Align the pipe and pump outlet and keep vertical, then screw in clockwise.

3.) Handle the pump carefully. When suspending the pump to raise or to lower it, attach a wire rope or a chain to the pump's handle.



4.) Install the pump only in an area that can maintain a proper water level.

NOTE:

For details on the water level necessary for pump operation, refer to the section on "Water Level During Operation" on page 20 of this manual.

5.) The discharge hose can be run vertically or horizontally, but must be without sharp bends.



6.) When using a hose to provide piping to the pump, observe the following: Use the shortest possible length of discharge hose and minimize the number of bends. Verify that the end of the hose (discharge side) is lifted above the water surface. If the end of the hose is submerged in water, it may cause the water to flow back when the pump has been stopped. If the end of the hose is located at a level that is lower than that of the source water surface, water may continue to flow out even after the pump has been stopped.



CAUTION:

If an excessive amount of sediment is drawn into the pump, it may cause the pump to wear, which can lead to current leakage or electrical shock.

NOTE:

Appropriate piping materials must be provided by the user. Piping materials are not included with the product.

7.) The pump must be placed upright during operation. If there is a risk that the pump could be buried under the sediment, place the pump on a base made up of materials such as concrete blocks.

www.pumpeng.com.au

Make the Electrical Connections

General Precautions

ELECTRICAL WARNING:

Do not megger test CT/CTS pump as these pumps are equipped with electronic smarts and these can be damaged using an electrical megger tester.

ELECTRICAL HAZARD:

• A certified electrician must supervise all electrical work. Comply with all local codes and regulations.



- Before starting work on the unit, make sure that the unit and the control panel are isolated from the power supply and can not be energized. This applies to the control circuit as well.
- Leakage into the electrical parts can cause damaged equipment or a blown fuse.
- Make sure that all unused conductors are insulated.
- There is a risk of electrical shock or explosion if the electrical connections are not correctly carried out or if there is fault or damage on the product.



WARNING:

Do not install the starter equipment in an explosive zone unless it is explosion proof rated.

Requirements

These general requirements apply for electrical installation:

- The mains voltage and frequency must agree with the specifications on the data plate.
- The fuses and circuit breakers must have the proper rating, and the pump overload protection (motor protection breaker) must be connected and set to the rated current according to the data plate and if applicable the cable chart. The starting current in direct-on-line start can be up to six times higher than the rated current.
- The fuse rating and the cables must be in accordance with the local rules and regulations.
- If intermittent operation is prescribed, then the pump must be provided with monitoring equipment supporting such operation.

Grounding

ELECTRICAL HAZARD:

- You must ground all electrical equipment. This applies to the pump equipment, the driver, and any monitoring equipment. Test the ground lead to verify that it is connected correctly.
- If the motor cable is jerked loose by mistake, the ground conductor should be the last conductor to come loose from its terminal. Make sure that the ground conductor is longer than the phase conductors. This applies to both ends of the motor cable.
- Risk of electrical shock or burn. You must connect an additional ground fault protection device to the grounded connectors if persons are likely to come into physical contact with the pump or pumped liquids.



WARNING:

To prevent damaging the pump and causing current leakage, which may lead to electrical shock, be sure to install the ground wire securely.



CAUTION:

To prevent electrical shock caused by improper grounding, do not connect the ground wire to a gas pipe, water pipe, lightning rod, or telephone ground wire.

Connecting the Cables

Installation

These are the requirements to follow when you install cables:

- The cables must be in good condition, not have any sharp bends, and not be pinched.
- The sheathing must not be damaged and must not have indentations or be embossed (with markings, etc.) at the cable entry.
- The cable entry seal sleeve and washers must conform to the outside diameter of the cable.
- The minimum bending radius must not be below the accepted value.
- If using a cable which has been used before, a short piece must be peeled off when refitting it so that the cable entry seal sleeve does not close around the cable at the same point again. If the outer sheath of the cable is damaged, then replace the cable. Contact PumpEng service shop.
- The voltage drop in long cables must be taken into account. The drive unit's rated voltage is the voltage measured at the cable connection point in the pump.



WARNING:

Before connecting the cable to the terminal board, make sure that the power supply (i.e. circuit breaker) is properly disconnected. Failure to do so may lead to electrical shock, short, or injury caused by the unintended starting of the pump.

CAUTION:

 If the cable must be extended, use an extension cable with the same or larger core size as that of the cable that is provided with the pump. Using a cable of proper size will prevent the motor from attaining its full potential or may cause the cable to over heat, which may lead to fire, current leakage, or electrical shock.



- If a cable with a cut or damaged sheath is submerged in water, the water may enter the pump and cause the motor to short. This will damage the pump, which may lead to current leakage, or electrical shock, or burn-out.
- To prevent the cable from cuts or twists, which will damage the pump and may lead to current leakage, electrical shock, or fire, be sure that the tires of vehicles do not run over the cable.
- If the cable must be submerged in water, be sure to mold the connection potion completely. Failure to do so may lead to current leakage, electrical shock, or burn-out.

Never submerge the ends of a cable in water.



If the cable must be extended, use an extension cable with the same or larger core sizes as that of the cable that is provided with the pump.



www.pumpeng.com.au

To prevent water from entering inside the cable, be sure to securely mold the cable connection portion. To avoid damaging the cable, arrange the cable run so that the cable is not bent, kinked, or pressed against a structure.



Tighten the ends of the cable securely against the terminal board.

The figure below shows how to connect the three phase cable properly.





(2)

(3)



Electric Circuit Diagrams

Installation

Direct-on-line starting







Three phase (2)



CTS (3)



Precautions

DANGER:

If you need to work on the pump, make sure that it is isolated from the power supply and cannot be energized.

WARNING:

- Never operate the pump without safety devices installed.
- Never operate the pump with the discharge hose blocked, or the discharge valve closed.
- Make sure you have a clear path of retreat.
- Never work alone.

CAUTION:

If the pump is equipped with automatic level control and/or internal contractor, there is a risk of sudden restart.



Distance to Wet Areas

ELECTRICAL HAZARD:

- Risk of electrical shock. Make sure no one gets closer than 20 m to the unit when being in contact with the pumped or mixed liquid.
- Risk of electrical shock. This unit has not been investigated for use in swimming pools. If used in connection with swimming pools special safety regulations apply.

Before Operation



CAUTION:

 Improper voltage and frequency of the power supply will prevent the pump from attaining its full potential, and may also lead to current leakage, electrical shock or fire.

- 1.) Once again, check the nameplate of the pump to verify that its voltage and frequency are correct.
- Check the wiring, power supply voltage, the capacity of the ground leakage circuit breaker, and the insulation resistance of the motor.

NOTICE:

Insulation resistance reference value \geq 30M Ω . Please refer page 9 for the test method.

3.) Adjust the setting of the overflow protector (i.e. circuit breaker) to the pump's rated current.

NOTICE:

Verify the rated current on the pump's nameplate.

4.) When using a generator, as much as possible avoid operating the pump in conjunction with other types of equipment.

Trial Operation

WARNING:

- Make sure that the unit can not roll or fall over and injure people or damage property.
- In some installations, the pump and the surrounding liquid may be hot. Bear in mind the risk of burn injuries.
- Make sure nobody is close to the unit when it is started. The unit will jerk in the opposite direction of the impeller rotation.

CAUTION:

Make sure to check the pump's direction of rotation when the pump is exposed to atmosphere. Operating the pump in reverse while it is submerged in water will damage the pump, which may lead to current leakage, electrical shock, or file.

NOTE:

- Inspect the pump. Check that there is no physical damage to the pump or cabins.
- Check the oil level in the oil housing.
- Remove the fuses or open the circuit breaker, and check that the impeller can be rotated freely.
- . Check that the monitoring equipment (if any) works.
- 1.) Operate the pump for a short time (1 to 2 seconds), and then check the correct pump rotation.

WARNING:



Before changing the connections for reverse rotation, make sure that the power supply (i.e. circuit breaker is properly disconnected and that the impeller has stopped completely. Failure to observe this may lead to serious accidents, including electrical shock.

• Use a phase rotation indicator to check the correct pump rotation.

NOTICE:

When using a phase rotation indicator, please read the operation manual with it.

Two ways to check the correct pump rotation

- 1. By looking at the impeller; the rotation of the impeller should be counter clockwise as shown in the picture 1.
- 2. By looking from the top of the pump. Since the impeller can not be seen, the best way to check the rotation is check the kick back motion of the pump when the pump just starts. The kick back motion of the pump should be counter clockwise as shown in the picture 2.



NOTE:

For CTS, you should use a screw driver metal body so that the water level sensor probe and guide rod connected, otherwise the pump can not start.

For pump with float switch, you should hand the float to pick up, otherwise the pump can not start.

To reverse the rotation about three phase, the following countermeasure must be taken.

COUNTERMEASURE:

Interchange two of the three wires designated U, V, and W, respectively.



- 2.) Operate the pump for a short time (≤1 minutes) and perform the following checks:
- Operating current Use an AC ammeter (clamp), measure the current at the phase U, V, and W that are connected to the terminal board.
- Operating voltage

Use an AC voltmeter (tester) to measure the voltage at the terminal board.

Power supply voltage tolerance = within $\pm 10\%$ of the rated voltage.

Vibration



CAUTION:

If the pump generates a considerable amount of vibration, noise, or smell, disconnect the power supply immediately and contact the dealer where you purchased the equipment or the PumpEng sales office in your area.

Continue operations if no abnormal conditions are found during the trial operation.

Operation

WARNING:

- The pump may be extremely hot during operation. To prevent burns, do not touch the pump with bare hands.
- Do not insert your finger or a stick into the pump's inlet opening. Doing so may cause injury, electrical shock, short or fire.
- When the pump is not used for a long time, make sure that the power supply (such as breaker) is properly disconnected. If the wiring insulation deteriorates with the power supply connected, it may cause current leakage, electrical shock or fire.

WARNING:



- During inspection and repair, disconnect the power supply to avoid starting the pump unintentionally. Failure to disconnect the power supply may lead to serious accidents including electrical shock, short, and injury.
- During a power outage, disconnect the power resumption would be extremely dangerous to people around the pump.

CAUTION:

• Unless the cause of a problem is removed, the pump will repeat the stop-and-go cycle, eventually resulting in damage to the pump, and causing current leakage and electrical shock. Therefore, after verifying that the power supply is disconnected, find and correct the cause of the problem through inspection and repair.



• Do not operate the pump at unusually low head, or when the strainer is clogged with debris. Doing so will prevent the pump from attaining its full potential, and may also generate abnormal noise and vibration an cause damage to the pump, which may lead to current leakage, electrical shock and fire.

To protect the motor, if a current overload occurs in the motor or if the motor overheats under the conditions given below, the pump will stop automatically, regardless of the water level during operation.

- Extreme fluctuation of power supply voltage.
- Pump overheated under overload condition.
- Pump operated at open phase or binding condition.

Motor Protection System



• To protect the motor from current surges, be sure to install a motor breaker, thermal relay or similar device in the external starting console or control panel.

Water Level During Operation

Operation

Pay attention to the water level during operation. The pump will become damaged if it is allowed to operate dry.

CAUTION:

• Do not operate the pump below Continuous running Water Level (C.W.L), as doing so will damage the pump, causing current leakage and electrical shock.

The table below shows the water level during operation by output. Make sure that the water level will not be under these levels.

MODEL	C.W.L.
CT 0.25~0.75kW	50mm
CT/CTS 1.5~2.2kW	87mm
CT/CTS 3.7~5.5kW	76mm
CT/CTS 7.5~11kW	142mm



The water level for the models which is not included in the tables: as per the picture shown: the lowest water level should submerge the pump body.

Maintenance and Inspection

Precautions

DANGER:

Disconnect and lock out electrical power before installing or serving the unit.

WARNING:

- Always follow safety guidelines when working on the product.
- Make sure that the unit cannot roll or fall over and injure people or damage property.
- Rinse the unit thoroughly with clean water before working on the unit.
- Rinse the components in water after dismantling.

Make sure that you follow these requirements:

- Check the explosion risk before you weld or use electrical hand tools.
- Allow all system and pump components to cool before you handle them.
- Make sure that the product and its components have been thoroughly cleaned.
- Do not open any vent or drain valves or remove any plugs while the system is pressurized. Make sure that the pump is isolated from the system and that pressure is relieved before you disassemble the pump, remove plugs, or disconnect piping.

Washing the Pump

Remove any debris attached to the pump's outer surface, and wash the pump with tap water. Pay particular attention to the impeller area, and completely remove any debris from the impeller.

Inspecting the Pump Exterior

Verify that the paint is not peeled, that there is no damage, and that the bolts and nuts have not loosened. If the paint has peeled, allow the pump to dry and apply touch-up paint.

NOTE:

Touch-up paint must be provided by the user. If the pump must be disassembled due to damage or loose bolts or nuts, contact the dealer from whom you purchased the equipment or the PumpEng sales office in you area.

Inspection

Maintenance and Inspection

INTERVAL	INSPECTION ITEM
	 Measuring insulation resistance Cold insulation resistance reference value ≥20MΩ (cold). Thermal insulation resistance reference value ≥1MΩ (thermal). NOTE: The motor must be inspected if the insulation resistance is considerably lower than that obtained during the last inspection.
Monthly	 Measuring the loaded current To be within the rated current Measuring the power supply voltage Power supply voltage tolerance a. continuous running: max±5% of the rated voltage. b. intermittent running: max±10% of the rated voltage. Inspecting the impeller If the performance level has decreased consider ably, the impeller maybe worn.
Semi-annually	Inspection of lifting chain or rope.Inspecting and changing oil.
Yearly	 Changing the oil and replacing the mechanical seal in the chamber. Every 12 months or after 6,000 hours of use, whichever comes first. NOTE: Contact the dealer from whom you purchased the equipment or the PumpEng sales office in your area to inspect and replace the mechanical seal.
Once every 2 to 5 years	 Overhaul The pump must be overhauled even if the pump appears normal during operation. The pump may need to be overhauled earlier if it is used continuously or repeatedly. NOTE: Contact the dealer from whom you purchased the equipment or the PumpEng sales office in your area to overhaul the pump.

Storage

If the pump will not be operated for a long period of time, pull the pump up, allow it to dry, and store it indoors.

NOTE:

Be sure to perform a trial operation before reinstalling the pump. If the pump remains immersed in water, operate the pump on a regular basis (i.e. once a week) to prevent the impeller from seizing due to rust.

Maintenance and Inspection Inspecting Oil and Changing Oil

Inspecting Oil

- Designated oil: Turbine oil VG32
- Oil volume: Specified volume

Remove the oil plug and take out a small amount of oil. The oil can be extracted easily by tilting the pump so that the oil plug faces downward. If the oil appears discolored or intermixed with water, a likely cause is a defective shaft sealing device (i.e. mechanical seal), which requires that the pump be disassembled and repaired.

Changing Oil

Remove the oil plug and drain the oil completely. Pour a specified volume of oil into the oil filter inlet.



NOTE:

- The drained oil must be disposed of by waste disposal contractors in compliance with the laws of the located where the pump is being used.
- The gasket and the O-ring for the oil filler plug must be replaced with a new part at each oil inspection and change.

Model	Specified oil volume(ml)
CT 0.25~0.75kW	190
CT/CTS 1.5~2.2kW	460
CT/CTS 3.7~5.5kW	440
CT/CTS 7.5~11kW	960



Maintenance and Inspection

The oil volume for the models which is not included in the tables: about 80% of the total oil cylinder capacity (theoretically, the oil level should cover the mating ring).

The parts listed below are dispensable items. As a rule of thumb, use the replacement period as a guide to replacing these parts.

Part Name	Replacement Condition
Gasket and O-ring	Each disassembly or inspection
Oil seal	Each disassembly or inspection or if the sealing lip is worn
Shaft sleeve	When worn

Disassembly and Reassembly Procedure



Disconnect and lock out electrical power before installing or serving the unit.



A worn impeller and/or pump housing can have very sharp edges. Wear protective gloves.

	Δ		
/	ļ	\mathbf{N}	
	-		

CAUTION:

Make sure to perform a trial operation when starting the pump after a reassembly. If the pump was assembled improperly, it may lead to abnormal operation , electrical shock or water damage.

Disassembly Procedure for CT 0.25~0.75kW

NOTE:

Before disassembling, be sure to drain the oil from the pump.

- Removing the strainer stand Remove the hexagonal nut and the plain washer from the bottom and remove the strainer stand from the pump.
- Removing the agitator
 Remove the agitator and the spring washer from the main shaft and remove the profiled pad.

Maintenance and Inspection

3.) Removing the suction cover

Remove the screw, plain washer and remove the suction cover, suction cover gasket from the pump.

4.) Removing the impeller

Remove the impeller, impeller adjusting washer, shaft sleeve from the main shaft.

5.) If necessary, remove the pump casing, O-ring and remove the mechanical seal. After removing the hexagonal bolt and the spring washer, remove the pump casing from the pump. At this time be careful not to damage the sliding surface of the mechanical seal. Remove the mechanical seal from the main shaft.

NOTE:

The exchange or maintenance of mechanical seal much be handled by the qualified staff. If you find any omissions, contact PumpEng sales office in your area.



Disassembly Procedure for CT 1.5~11kW Maintenance and Inspection

NOTE:

Before disassembling, be sure to drain the oil from the pump.

- Removing the strainer stand Remove the hexagonal nut and the plain washer from the bottom and remove the strainer stand (CTS: first step remove the Screw/Rod)
- 2.) Removing the diffuser Remove hexagonal bolt, spring washer, remove the diffuser, diffuser packing from the pump.
- 3.) Removing the impeller Using a box wrench, remove the cap nut, spring washer, and the washer; then remove the impeller, impeller adjusting washer, shaft sleeve from the main shaft.
- 4.) If necessary, remove the seal bracket, O-ring and remove the mechanical seal. After removing the hexagonal bolt, remove the seal bracket from bearing house. At this time, be careful not to damage the sliding surface of the mechanical seal. Remove the mechanical seal from the main shaft.

NOTE:

The exchange or maintenance of mechanical seal much be handled by the qualified staff. If you find any omissions, contact PumpEng sales office in your area.



Maintenance and Inspection

Reassembly Procedure

1.) The reassembly procedure is the reverse sequence of disassembly.

NOTE:

- After completing reassembly, do not forget to pour the specified amount of oil into the pump.
- The gaskets and O-rings must be replaced with new parts. Also replace any parts that are worn or damaged.
- 2.) Using a clean rag without oil, wipe the sliding surface of the mechanical seal. Apply oil to the outer circumference of the cushion rubber to facilitate insertion.

NOTE:

For further details on how to install the mechanical seal, refer to the "Mechanical seal handing procedure" that comes with the mechanical seal that is sold separately as a space part.

- 3.) After installing the impeller, and after completing the reassembly, check that the impeller rotates smoothly and that it does not come on contact with the diffuser.
- 4.) To make sure that the pump operates normally, perform a trial operation before placing the pump back into service.

Trouble Shooting

	Λ	
/	1	\mathbf{N}
/	ě	_ \

DANGER:

Personal injury hazard. Troubleshooting a live control panel exposes personnel to hazardous voltages. Electrical troubleshooting must be done by a qualified electrician. Failure to follow these instructions will result in serious personal injury, death, and/or property damage.



WARNING:

Always disconnect and lock out power before servicing to prevent unexpected startup. Failure to do so could result in death or serious injury.

Read this operation manual carefully before requesting repair. After re-inpecting the pump, if it does not operate normally, contact the dealer from whom you purchased the equipment, or the PumpEng sales office in your area.

Trouble Shooting

SYMPTOM	CAUSE	COUNTERMEASURE
Pump fails to start	No power is supplied (i.e. power outage).	Contact the electric power company or an electrical repair shop.
	Open circuit or poor connection of the cable.	Check if there is an open circuit in the cable or wiring.
	Automatically control faults (control panel).	Check the reason and then ask experts to repair.
	Impeller is obstructed.	Inspect the pump and remove the obstruction.
Pump starts but stops immediately, causing the motor protector to actuate.	Impeller is obstructed.	Inspect the pump and remove the obstruction.
	Voltage drop.	Correct the voltage to the rated voltage, or use an extension cable that meets the standard.
	Failure round thermal protector or protective device.	Replacement or adjustment
	A 50 Hz model is operated at 60 Hz.	Check the nameplate and replace the pump or the impeller.
	The strainer is obstructed and the pump was operated dry for long hours.	Remove the obstruction.
	The impeller or suction cover is worn.	Replace.
The pump's head and pumping volume is lower.	The hose may be kinked or clogged.	Minimize the number of bends in the hose. (In an area with a large amount of debris, use the pump in a meshed basket.)
	The submerged depth of pump is too shallow, there is air inhalation.	Adjust the submerge depth until the pump is submerged.
	Check if the gate valve is open.	Open gate valve.
	The strainer is obstructed or buried.	Remove the obstruction. Place a concrete block under the pump to prevent the pump from picking up sediment.
	The motor rotates in reverse.	Interchange the power supply terminal connection.
The pump generates noise or vibration.	The bearing of the motor may be damaged.	To replace the bearing, contact the dealer from whom you purchased the equipment or the PumpEng sales office in your area.
	The shaft is bending.	Correct or contact with the nearest agency of PumpEng.



Tough Submersible Pumps

Perth

1/88 Renewable Chase Bibra Lake WA 6163

📞 (08) 9434 9922

Kalgoorlie

8 Keogh Way Calgoorlie WA 6430

(08) 9021 5965

Mount Isa

Mount Isa QLD 4825

C 0457 006 407

Email us: sales@pumpeng.com.au

www.pumpeng.com.au