


SURESEAL ISO



SECTIONAL ARRANGEMENT

ITEM No.	DESCRIPTION	ITEM No.	DESCRIPTION
1	VOLUTE CASING	20	CASING GASKET
2	IMPELLER	21	CASING BOLT/STUD/NUT
3	BACKPLATE	22	BACK COVER BOLT/STUD/NUT
4	BEARING PEDESTAL	23	SEAL/GLAND PLATE STUD
7	MECHANICAL SEAL	23a	GLAND SETTING SPACER
7a	GLAND PACKING	24	BEARING COVER BOLT
8	SHAFT SLEEVE	25	COUPLING KEY
8a	SHAFT SLEEVE GASKET – SURESEAL	26	SUPPORT FOOT BOLT
9	SEAL/GLAND PLATE	27	SUPPORT FOOT
10	WATER SLINGER	28	IMPELLER WASHER
11	SHAFT	29	SUCTION FLANGE PLUG
12	BEARING N.D.E.	30	DISCHARGE FLANGE PLUG
13	BEARING D.E.	31	SEAL/GLAND PLATE NUT
14	BEARING COVER	32	SEAL/GLAND PLATE WASHER
15	IMPELLER NUT	33	SUPPORT FOOT NUT
16	IMPELLER KEY	34	SUPPORT FOOT WASHER
17*	FRONT CASING WEAR RING	35	LIP SEAL
18	DRAIN PLUG	36	GREASE NIPPLE
19*	REAR CASING WEAR RING		

* DENOTES OPTIONAL WEAR RINGS

No	DATE	REVISION	Title SURESEAL ISO 2858 SECTIONAL ARRANGEMENT MECHANICAL SEAL PUMP	Reference SURESEAL Rev. B
B	Aug '07	SURESEAL MODS		
A	May '07	INITIAL ISSUE		