


# SERIES 1



SECTIONAL ARRANGEMENT

ITEM No.	DESCRIPTION	ITEM No.	DESCRIPTION
1	VOLUTE CASING	19	REAR CASING WEAR RING
2	IMPELLER	20	CASING GASKET
3	BACKPLATE	21	CASING BOLT/STUD
4	BEARING PEDESTAL	22	BACK COVER BOLT
6	SEAL PLATE GASKET	23	SEAL PLATE STUD
7	MECHANICAL SEAL	24	BEARING COVER BOLT
8	MECHANICAL SEAL COLLAR	25	COUPLING KEY
9	MECHANICAL SEAL PLATE	26	SUPPORT FOOT BOLT
10	WATER SLINGER	27	SUPPORT FOOT
11	SHAFT	28	IMPELLER WASHER
12	BEARING N.D.E.	29	SUCTION FLANGE PLUG
13	BEARING D.E.	30	DISCHARGE FLANGE PLUG
14	BEARING COVER	32	SEAL PLATE WASHER
15	IMPELLER NUT	33	SUPPORT FOOT NUT
16	IMPELLER KEY	34	SUPPORT FOOT WASHER
17	FRONT CASING WEAR RING	36	GREASE NIPPLE
18	DRAIN PLUG		

			Title <b>SERIES 1 SECTIONAL ARRANGEMENT MECHANICAL SEAL PUMP</b>	Reference <b>S1P-MS01</b> Rev. B
B	Mar. '03	GENERAL UPDATE		
A	May. '02	INITIAL ISSUE		
No	DATE	REVISION		